

# Hisense

## USE AND INSTALLATION INSTRUCTIONS

### **Turbo Inverter: Super Inverter:**

AUW26U4RS8

AUW40U4RS7

AUW35U4RS8

AUW52U4RS7

AUW40U4RJ8

AUW60U4RJ7

AUW52U4RJ8

AUW71U4RJ7

AUW60U4RK8

AUW105U4RK7

AUW71U4RK8

AUW105U6RN8

AUW125U6RN8

AUW140U6RN8

AUW200U6RZ8

AUW250U6RZ8

Thank you very much for purchasing this Air Conditioner. Please read this use and installation instructions carefully before installing and using this appliance and keep this manual for future reference.

ENGLISH

POLSKIE

УКРАЇНЬКА

ROMÂNĂ

Български

ΕΛΛΗΝΙΚΑ

SRPSKI

HRVATSKI

ČEŠTINA

MAGYAR

## Contents

<b>Safety Precautions .....</b>	<b>1</b>
<b>Electrical Wiring Diagram.....</b>	<b>8</b>
<b>Installation Instructions .....</b>	<b>9</b>
Transportation and Handling before Installation .....	9
Installation Location Selection.....	9
Drainage Elbow and Drain Hose Installation.....	10
Outdoor Unit Installation.....	10
Refrigerant Piping .....	11
Wiring .....	14
Trial Run .....	16


## Safety Precautions

1. This air conditioner uses new refrigerant HFC (R32).
2. The max. working pressure is 4.3MPa (R22: 3.1MPa). Some of the piping and installation and service tools are special.

Please read these SAFETY PRECAUTIONS carefully to ensure correct installation.

- Be sure to use a dedicated power circuit, and do not put other loads on the power supply.
- Be sure to read these SAFETY PRECAUTIONS carefully before installation.
- Be sure to comply with SAFETY PRECAUTIONS of installation manual, because it contains important safety guidelines. Definitions for identifying hazards levels are provided below with their respective safety symbols.

 **WARNING:** Hazards or unsafe practices which COULD result in severe personal injury or death.

 **CAUTION:** Hazards or unsafe practices which COULD result in minor personal injury or product or property damage.

- File indoor and outdoor unit manual away for future reference.
- For more product information, please refer to the specs or other technical files.

### **WARNING**

- Installation should be performed by a qualified licensed service provider. .  
Improper installation may cause fire, electric shock or water leakage.
- Perform the installation properly by referring to the installation manual.  
Improper installation may cause personal injury fire, electric shock, unit falling or water leakage.
- Install the air conditioner on a solid base that can support the unit weight.  
An inadequate base or improper installation may cause injury in the event the unit falls off the base.
- Wiring must be done by the qualified electrician. All the electric works must be performed in accordance with national wiring regulations and local electrical codes.
- Use the specified type of wire for electrical connections safely.  
Firmly clamp the interconnecting wires so that their terminals receive no external stresses.
- Use a cable long enough to cover the entire distance with no connection. Do not connect multiple devices to the same AC power supply.  
Doing so it may result in bad contact, poor insulation, or over current resulting in fire or electric shock.
- After all installations are completed, make sure that there are no refrigerant leaks.  
Leaked refrigerant gas may generate harmful substance when the gas comes in contact with a heat source, or open flame.
- If the power supply circuit capacity or electrical work is not in place, it may cause a fire or electric shock.
- Install the electrical cover to the indoor unit and the service panel to the outdoor unit securely.
- If the electrical cover on the indoor unit or the service panel of the outdoor unit are not installed properly, it could result in fire or electric shock due to dust water, etc.
- Disconnect the main power supply before the installation of indoor electronic PCB or wiring.  
Failure to do so will result in electric shock.
- Select outdoor unit installation location carefully, avoid people or other small animals contact with electrical components. Please keep the surrounding environment of the outdoor unit clean and tidy.
- When installing or relocating the unit, make sure that no substance other than the specified refrigerant (R32) enters the refrigerant circuit.  
Any presence of foreign substance such as air can cause abnormal pressure rise or an explosion.

# Safety Precautions



- Perform grounding  
Do not connect the earth wire to a gas pipe, water pipe, lightning rod or telephone earth wire. Defective grounding could cause electric shock.
- Do not install the unit in a place where an inflammable leak is possible.  
If gas leaks and accumulates in the area surrounding the unit, it could cause an explosion.
- Tighten a flare nut with a torque wrench as specified in this manual.  
When fastened too tight, a flare nut may break after a long period, thereby causing refrigerant leakage.
- Install an earth leakage breaker depending on the installation place (where local code requires humid).  
If an earth leakage breaker is not installed, it could cause an electric shock.
- Perform the drainage/piping work securely according to the installation manual.
- If there is a defect in the drainage/piping work, water could leak from the unit and household goods could become wet and damaged.

## Safety instructions

- Do not let air enter the refrigeration system or discharge refrigerant when moving the air conditioner.
- The installation instructions for appliances that are intended to be permanently connected to fixed wiring, and have a leakage current that may exceed 10 mA, shall state that the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.  
Children should be supervised to ensure that they do not play with the appliance.
- If the appliance has permanently fixed wiring, the appliance must be fitted with means for disconnection from the supply mains having a contact separation in all poles that provide full disconnection under over voltage category III conditions, and these means must be incorporated in the fixed wiring in accordance with the wiring rules.
- If the supply cord is damaged, it must be replaced by a qualified contractor, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance shall be installed in accordance with national wiring regulations.
- Servicing shall only be performed as recommended by the equipment manufacturer.
- The method of connection of the appliance to the electrical supply and interconnection of separate components is detailed in below part. The wiring diagram with a clear indication of the connections and wiring to external control devices and supply cord is detailed in below part. The cord of the H07RN-F type or the electrically equivalent type must be used for power connection and interconnection between outdoor unit and indoor unit. The size of the cord is detailed in below part.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- It is necessary to allow disconnection of the appliance from the electrical supply after installation.  
The disconnection may be achieved by incorporating a switch in the fixed wiring in accordance with the wiring rules. During service and when replacing parts, be sure to disconnect the appliance from its power source. If the disconnection is not foreseen, and provide a disconnection with a locking system in the isolated position.
- Details of type and rating of fuses, or rating of circuit breakers / ELB is detailed in below parts.
- The information of dimensions of the space necessary for correct installation of the appliance including the minimum permissible distances to adjacent structures is detailed in below details.
- This appliance is intended to be used by expert or trained technicians, in shops, in light industry and in light commercial applications, or for commercial applications.
- Instructions on additional charging of refrigerants are detailed below.

# Safety Precautions

## Precautions for using R32 refrigerant

The basic installation work procedures are the same as the conventional refrigerant (R22 or R410A). However, pay attention to the following points:

### WARNING

#### 1. Transport of equipment containing flammable refrigerants.

Attention is drawn to the fact that additional transportation regulations may exist with respect to equipment containing flammable gas. The maximum number of pieces of equipment or the configuration of the equipment, permitted to be transported together will be determined by the applicable transport regulations.

#### 2. Marking of equipment using signs

Signs for similar appliances (containing flammable refrigerants) used in a work area generally are addressed by local regulations and give the minimum requirements for the provision of safety and/or health signs for a work location. All required signs are to be maintained and employers should ensure that employees receive suitable and sufficient instruction and training on the meaning of appropriate safety signs and the actions that need to be taken in connection with these signs. The effectiveness of signs should not be diminished by too many signs being placed together. Any pictograms used should be as simple as possible and contain only essential details.

#### 3. Disposal of equipment using flammable refrigerants

Compliance with national regulations

#### 4. Storage of equipment/appliances

The storage of equipment should be in accordance with the manufacturer's instructions.

#### 5. Storage of packed (unsold) equipment

- Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge.
- The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.

#### 6. Information on servicing

##### 6-1 Checks to the area

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions should be complied with prior to conducting work on the system.

##### 6-2 Work procedure

Work shall be undertaken under a controlled procedure so as to minimise the risk of flammable gas or vapour being present while the work is being performed.

##### 6-3 General work area

- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

##### 6-4 Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

##### 6-5 Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand.
- Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

##### 6-6 No ignition sources

- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

##### 6-7 Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

##### 6-8 Checks to the refrigeration equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.

# Safety Precautions

## WARNING

- The following checks shall be applied to installations using flammable refrigerants:
  - The charge size is in accordance with the room size within which the refrigerant containing parts are installed;
  - The ventilation machinery and outlets are operating adequately and are not obstructed;
  - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
  - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
  - Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

### 6-9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
  - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
  - That there no live electrical components and wiring are exposed while charging, recovering or purging the system;
  - That there is continuity of earth bonding.

### 7. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
  - If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
  - Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
  - This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
  - Ensure that apparatus is mounted securely.
  - Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
  - Replacement parts shall be in accordance with the manufacturer's specifications.
- NOTE: The use of silicon sealants may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

### 8. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

### 9. Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.



# Safety Precautions

## WARNING

### 10. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

### 11. Leak detection methods

- The following leak detection methods are deemed acceptable for systems containing flammable refrigerants:
- Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
  - Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
  - Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
  - Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
  - If a leak is suspected, all naked flames shall be removed/ extinguished.
  - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
  - Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

### 12. Removal and evacuation

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used.
- However, it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to:
  - Remove refrigerant;
  - Purge the circuit with inert gas;
  - Evacuate;
  - Purge again with inert gas;
  - Open the circuit by cutting or brazing.
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- The system shall be “flushed” with OFN to render the unit safe.
- This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for this task.
- Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

### 13. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
  - Ensure that contamination of different refrigerants does not occur when using charging equipment.
  - Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
  - Cylinders shall be kept upright.
  - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
  - Label the system when charging is complete (if not already).
  - Extreme care shall be taken not to overfill the refrigeration system.
  - Prior to recharging the system it shall be pressure tested with OFN.
- The system shall be leak tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.

### 14. Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.  
It is recommended good practice that all refrigerants are recovered safely.

# Safety Precautions

## WARNING

Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
  - Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - All personal protective equipment is available and being used correctly;
  - The recovery process is supervised at all times by a competent person;
  - Recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

### 15. Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.  
The label shall be dated and signed.  
Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

### 16. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge is available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
- Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.



# Safety Precautions





## ⚠ WARNING

- The pipe-work shall be complied with national gas regulations.
- The maximum refrigerant charge amount is X kg (X see below).
- When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the unit.
- Do not place any other electrical products or household belongings under indoor unit or outdoor unit.
- Condensation dripping from the unit might get them wet, and may cause damage or malfunction of your property.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- To keep ventilation openings clear of obstruction.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- The appliance shall be stored in a room without continuously operating open flames (for example an operating as appliance) and ignition sources (for example an operating electric heater).
- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer.
- Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- The appliance shall be installed and stored so as to prevent mechanical damage from occurring.
- Mechanical connectors used indoors shall comply with ISO 14903. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.
- The installation of pipe-work shall be kept to a minimum.
- Mechanical connections shall be accessible for maintenance purposes.

**Max. Refrigerant Charge Amount X(kg)**


Series	Model	26	35	40	52	60	71	105	125	140	200	250
Super Inverter	Max. Refrigerant charge (kg)	/	/	1.600	1.600	2.900	2.900	4.000	/	/	/	/
Turbo Inverter	Max. Refrigerant charge (kg)	1.245	1.245	1.875	1.875	3.075	3.075	4.190	4.840	4.840	6.960	6.960

Explanation of symbols displayed on the indoor unit or outdoor unit.


	<b>WARNING</b>	This symbol shows that this appliance uses a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	<b>CAUTION</b>	This symbol shows that the operation manual should be read carefully.
	<b>CAUTION</b>	This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.
	<b>CAUTION</b>	This symbol shows that information is available such as the operating manual or installation manual.

# Electrical Wiring Diagram

## Electrical Wiring Diagram



Single phase models



Three phase models

# Installation Instructions


## Transportation and Handling before Installation

Transport the product as close to the installation location as possible before unpacking.

### • Handling Method


When handling the unit, ensure a balance of the unit, check safety and lift it up smoothly.

- (1) Do not remove any packing materials.
- (2) Hang the packaged unit condition with two ropes, as shown in Fig. below.



### • Handling

If there is no packaging in place, please protect with cloth or paper.



## Installation Location Selection


**Before choosing the installation site, obtain user approval.**

- Where it is not exposed to strong wind.
- Where airflow is good and clean.
- Where it is not exposed to direct water runoff from roof.
- Where neighbors are not annoyed by operation sound or hot air.
- Where rigid wall or support is available to prevent the increase of operation sound or vibration.
- Where there is no risk of combustible gas leakage.
- Where it is at least 10 ft. (3m) away from the antenna of TV set or radio. An amplifier may be required for the affected device.
- Install the unit levelly.
- Please install it in an area not affected by snowfall or blowing snow. In areas with heavy snow, please install a canopy, a pedestal and/or some baffle boards.

### ⚠ CAUTION:

Avoid the following places for installation where air conditioner trouble is liable to occur.

- Where there is much machine oil.
- Salty places such as seaside.
- Where sulfide gas is generated such as a hot spring.
- Where there is high-frequency or wireless equipment.



Note:

When operating the air conditioner in low ambient temperature, be sure to follow the instruction described below.


- Never install the outdoor unit in a place where its air inlet/outlet side may be exposed to high winds.
- To prevent exposure to wind, install the outdoor unit with its air inlet side facing the wall.
- To prevent exposure to wind, it is recommended to install a wind baffle board on the air outlet side of the outdoor unit.

# Installation Instructions

## Drainage Elbow and Drain Hose Installation

Install Drainage Elbow and Drain Hose

- The condensate water may drain from the outdoor unit when the unit operates in heating mode. In order to avoid disturbing neighbors and to protect the environment, it is necessary to install a drainage elbow and a condensate drain hose to drain out the condensate water.
- Perform drainage work before the indoor unit and outdoor unit are connected. Otherwise, it will be difficult to install drainage elbow after the machine becomes immovable.)
- Connect the drain hose [field-supplied, inside diameter: 5/8 in. (15mm)] as shown in the figure for drainage.




Note:

- Do not use the drainage elbow in the cold region. Drain may freeze.
- Drain hose and Drainage elbow are not valid for 200/250 air-conditioners.

## Outdoor Unit Installation

- (1) Use the washers to fasten the machine at the foundation bolts.
- (2) When fastening the outdoor unit with the foundation bolts, the fasten holes position as the Fig.1.
- (3) Fasten the outdoor unit as shown in Fig.2.
- (4) Make sure to fasten the outdoor unit tight and level to prevent noise from occurring.
- (5) Do not drain off water to the public places to hazardous slips/falls.
- (6) The strong base (made of concrete, etc.) should be made. The appliance should be placed not less than 4in. (10cm) high to avoid being wet or corroded. Otherwise, it may cause damage to the appliance or reduce its life time. (Fig.3)



(Unit:mm)

Model		A	B	C	D	E	F	d
Super Inverter	Turbo Inverter							
40/52	26/35	810	280	510	310	338	150	10×17
60/71	40/52	860	310	542	341	368	168	11×17
105	60/71	900	340	608	368	398	146	11×17
/	105/125/140	900	320	535	357	385	195	12×20
/	200/250	1100	390	570	428	470	265	16×24

Fig.1




Fig.2




Fig.3

# Installation Instructions

## Refrigerant Piping

### 1. Piping Requirement

Model	Outer Diameter of Pipe (mm)	
	Gas	Liquid
26/35	Φ9.52	Φ6.35
40/52	Φ12.7	Φ6.35
60~140	Φ15.88	Φ9.52
200/250	Φ22.22	Φ9.52

The shorter the refrigerant piping length is, the better. So the connecting pipe should be as short as possible.

Super Inverter	Min. pipe length (L)	Max. Pipe length (L)	Max. Height difference (H)	Turbo Inverter	Min. pipe length (L)	Max. Pipe length (L)	Max. Height difference (H)
40/52	3(m)	40(m)	30(m)	26/35	3(m)	30(m)	15(m)
60/71	3(m)	45(m)	30(m)	40~105	3(m)	50(m)	30(m)
105	3(m)	50(m)	30(m)	125/140	3(m)	60(m)	30(m)
				200/250	3(m)	75(m)	30(m)

#### Additional Refrigerant Charge

The unit has been filled with refrigerant.

For 26~52, The outdoor unit is pre-charged with refrigerant to accommodate a total piping length of 5m.

Additional refrigerant (R32) is required for extending the piping beyond 5m:

Additional refrigerant charge  $= (L - 5) \times 15\text{g/m}$

For 60/71/Super Inverter 105, The outdoor unit is pre-charged with refrigerant to accommodate a total piping length of 5m.

Additional refrigerant (R32) is required for extending the piping beyond 5m:

Additional refrigerant charge  $= (L - 5) \times 35\text{g/m}$

For Turbo Inverter 105~250, The outdoor unit is pre-charged with refrigerant to accommodate a total piping length of 7.5m.

Additional refrigerant (R32) is required for extending the piping beyond 7.5m:

Additional refrigerant charge  $= (L - 7.5) \times 35\text{g/m}$

### 2. Piping Material


- (1) Prepare locally-supplied copper pipes.
- (2) Select clean copper pipes. Make sure there is no dust and moisture inside the pipes. Blow the inside of the pipes with nitrogen or dry air, to remove any dust or foreign materials before connecting pipes.
- (3) Piping thickness and material are shown as below.

Diameter	Φ6.35	Φ9.52	Φ12.7	Φ15.88	Φ19.05	Φ22.22
Thickness	0.8	0.8	0.8	1.0	1.0	1.0

# Installation Instructions



CAUTION



## 3. Refrigerant piping work

### (1) Pipe cutting

Cut the copper pipe correctly with a pipe cutter.

### (2) Burrs removal

Completely remove all burrs from the cross section of the pipe. Orient the end of the copper pipe downward to prevent burrs from dropping in the pipe.

### (3) Putting nut on

Remove flare nuts attached to indoor and outdoor units, then put them on the pipe, burrs of which have been removed. (Not possible to put them on after flaring work). Flare nut for pipe depends on the diameter of pipe.


### (4) Flaring work

Perform flaring work with a flaring tool as shown below.

### (5) Check

Compare the flared work with the figure below.


If flare is noted to be defective, cut off the flared section and perform flaring work again.



(Unit: mm)

Diameter Φd	A <sup>+0</sup> <sub>-0.4</sub>
6.35	9.1
9.52	13.2
12.7	16.6
15.88	19.7
19.05*	24.0

\*: Perform the flaring work with type O material.



## 4. Piping connection

### (1) Confirm that the valve is closed.

(2) Connect the indoor unit and the outdoor unit with field-supplied refrigerant piping. Suspend the refrigerant piping at certain points and prevent the refrigerant piping from touching the weak part of the building such as wall, ceiling, etc. (If touched, abnormal sound may occur due to the vibration of the piping. Pay special attention in case of short piping length.)

(3) Tighten the flare nut with two spanners (one being a torque wrench) as shown in the right figure.

(4) Apply the refrigerant oil (field-supplied) thinly at the seat surface of the flare nut and pipe before connecting and tightening.

And when tightening the flare nut, use two spanners.

(5) Outdoor refrigerant piping should connect with stop valve.



Double Spanner work

Tube size (mm)	Torque (N·m)
φ 6.35	20
φ 9.52	40
φ 12.7	60
φ 15.88	80
φ 19.05	100

Tightening Torque for Flare Nut



# Installation Instructions

- (6) After finishing connecting the refrigerant pipes, insulate with proper insulation.
- For outside unit, insulate both pipes.
  - Cover piping joints with pipe cover.
  - Using piping tape, apply taping starting from the entry of outdoor unit.
    - Fix the end of piping tape with adhesive tape.
    - When piping has to be arranged through above ceiling, closet or area where temperature and humidity are high, install additional sold insulation for prevention of condensation.

## 5. Air tight test

- Do use Nitrogen.

Connect the gauge manifold using charging hoses with a nitrogen cylinder to the check joints of the liquid line and the gas line stop valves.

Perform pressure test.


Don't open the gas line stop valves.

Apply nitrogen gas pressure of 550 psig (3.8 MPa).


Check for any gas leakage at the flare nut connections, or brazed parts by gas leaks detector or foaming agent.

Gas pressure doesn't decrease, which is OK.

After the air tight test, release nitrogen gas.



Piping insulation procedure




Air tight procedure

## 6. Vacuum Pumping leaks Refrigerant Charge

- Vacuum pumping

- (1) Remove the service port cap of the stop valve on the gas pipe side of the outdoor unit.
- (2) Connect the manifold gauge and vacuum pump to the service port of the stop valve on the gas pipe side of the outdoor unit.
- (3) Run the vacuum pump. (Work for more than 15 minutes.)
- (4) Check the vacuum with the gauge manifold valve, then close the gauge manifold valve and stop the vacuum pump.
- (5) Leave it as is for one or two minutes. Make sure that the pointer of the manifold gauge remains in the same position. Confirm that the pressure gauge shows -14.7psig (-0.101MPa or -760mmHg).
- (6) Remove the manifold gauge quickly from the service port of the stop valve.
- (7) After refrigerant pipes are connected and evacuated, fully open all stop valves on both sides of gas pipe and liquid pipe.
- (8) Open adjusted valve to add refrigerant (the refrigerant is liquid).
- (9) Tighten the cap to the service port .
- (10) Retighten the cap.
- (11) Leak test foam with halogen leak detector to check the flare nut and brazing for leaks. Use foam that does not generate ammonia (NH3) in the reaction.



CAUTION

- An excess or a shortage of refrigerant is the main cause of trouble to the unit. Charge the correct quantity of refrigerant according to the description in the manual.
- Check for refrigerant leaks. If a large refrigerant leakage occurs, it will cause difficulty in breathing or harmful gases would occur if there is an open flame in the room.

# Installation Instructions

## • Additional refrigerant charge

The unit is pre-charged with refrigerant at the factory.

Please calculate additional charge according to "Piping Requirement".

After finishing vacuum pump procedures, first exhaust air from the charge hose, then open valves, charge refrigerant through liquid stop valve.

When finished, please close valves and record the refrigerant charge quantity.

## Wiring



### WARNING

- Turn OFF the main power switch of the indoor unit and the outdoor unit and wait for more than 3 minutes before electrical wiring work or a periodical check is performed.
- Check to ensure that the indoor fan and the outdoor fan have stopped before electrical wiring work or a periodical check is performed.
- Protect the wires, electrical parts, etc. from rats or other small animals. If not protected, rats may gnaw at unprotected parts and at the worst, a fire will occur.
- Avoid the wiring from touching the refrigerant pipes, plate edges and electrical parts inside the unit.  
If so, the wires will be damaged and at the worst, a fire will occur.
- Install an ELB (Electric Leakage Breaker) in the power source.  
If ELB is not used, it will cause electric shock or fire at the worst.
- This unit uses an inverter, which means that it must be used with an earth leak detector capable of handling harmonics in order to prevent malfunctioning of the earth leak detector itself.
- Do not use intermediate connection wires, stranded wires (see "**Attentions when Connecting the Power Supply Wiring**", extension cables or control line connection, because the use of these wires may cause heating, electric shock or fire.
- The tightening torque of each screw is shown as follows.  
M4: 0.7 to 1.0 lbf·ft. (1.0 to 1.3 N·m)  
M5: 1.5 to 1.8 lbf·ft. (2.0 to 2.5 N·m)  
M6: 3.0 to 3.7 lbf·ft. (4.0 to 5.0 N·m)  
M8: 6.6 to 8.1 lbf·ft. (9.0 to 11.0 N·m)  
M10: 13.3 to 17.0 lbf·ft. (18.0 to 23.0 N·m)  
Keep the above tightening torque during wiring work.



### CAUTION

- With tape material along the wire wrapped, sealed wiring holes, prevent the condensed water leaks and insects.
- Tightly secure the power source wiring by using the cord clamp inside the unit.

NOTE: Secure the rubber bushings with adhesive when conduit tubes to the outdoor unit are not used.

### General Check

- (1) Make sure that the field-selected electrical components (main power switches, circuit breakers, wires, conduit connectors and wire terminals) have been properly selected according to the electrical data.
- (2) Check to ensure that the capacity of power supply is enough.  
If not, the compressor will not be able to operate because of abnormal voltage drop at starting.
- (3) Check to ensure that the earth wire is connected.
- (4) Install a main switch, multi-pole main switch with a space of 3.5mm or more, single phase main switch with a space of 3.0mm or more between phases.
- (5) Check to ensure that the electrical resistance is more than 2MΩ, by measuring the resistance between ground and the terminal of the electrical parts. If not, do not operate the system until the electrical leakage is found and repaired.

# Installation Instructions

## Electrical data

Super Inverter	Turbo Inverter	Power Supply	ELB		Power Source Cable Size	Transmitting Cable Size	Circuit Breaker (A)
			Nominal Current (A)	Nominal Sensitive Current (mA)	EN60335-1*1	EN60335-1*1	
/	26/35	220-240V~, 50Hz	20	30	3×1.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	20
40/52	40/52	220-240V~, 50Hz	20	30	3×2.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	20
60/71	60/71	220-240V~, 50Hz	25	30	3×2.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	25
105	/	220-240V~, 50Hz	32	30	3×2.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	32
/	105	380-415V 3N~, 50Hz	25	30	5×1.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	25
/	125/140	380-415V 3N~, 50Hz	25	30	5×2.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	25
/	200/250	380-415V 3N~, 50Hz	32	30	5×2.5mm <sup>2</sup>	4×1.5mm <sup>2</sup>	32

**Max. Running Current (A): REFER TO NAMEPLATE**

### NOTE:

- (1) Follow local codes and regulations when field selecting wires, and all the above are of the minimum wire size.
- (2) Use the wires which are not lighter than the ordinary polychloroprene sheathed flexible cord. (Cord designation H07RN-F).
- (3) The wire sizes marked with \*1 in the above table are selected at the maximum current of the unit according to EN60335-1, or regional standards.
- (4) When the transmitting cable exceeds 15 meters, a larger wire size should be selected.
- (5) Install main switch and ELB (if required by local codes) for each system separately. Select the high response type ELB that is activated within 0.1second. For recommended capacity, see outdoor equipment switch capacity.
- (6) In the case that power cables are connected in series, add each unit maximum current and select wires as below.


### Selection According to EN60335-1

Current i(A)	Wire Size(mm <sup>2</sup> )
$i \leq 6$	0.75
$6 < i \leq 10$	1
$10 < i \leq 16$	1.5
$16 < i \leq 25$	2.5
$25 < i \leq 32$	4
$32 < i \leq 40$	6
$40 < i \leq 63$	10
$63 < i$	*


\* In the case that current exceeds 63A, do not connect cables in series.

### <Attentions when Connect the power supply wirings>

1. When connecting the terminal block using stranded wire, make sure to use the round crimp-style terminal for connection to the power supply terminal block. Place the round crimp-style terminals on the wires up to the covered part and secure in place.



2. When connecting the terminal block using a single core wire, be sure to perform curving.



# Installation Instructions

## Trial Run

Make sure that turn on electric power 6 hours before operating the unit.

Trial run should be performed after refrigerant piping, condensate drain, wiring, etc. have been finished.

Do not operate the system until all the check points have been cleared.

(A) Check to ensure that the stop valves of the outdoor unit are fully opened.

(B) Check to ensure the electric wires has been fully connected.

(C) Check to ensure that the electrical resistance is more than  $2M\Omega$ , by measuring the resistance between ground and the terminal of the electrical parts. If not, do not operate the system until the electrical leakage is found and repaired.

Trial run function identification

Operate remote controller turn ON, then proceed trial run.

Pay attention to the following items while the system is running.

Do not touch any of the parts by hand at the discharge gas side, since the compressor chamber and the pipes at the discharge side are heated higher than  $90^{\circ}\text{C}$ .

- Turn off the power after trial run is finished.

Installation of the appliance is generally finished after the above operations are done. If you still have any trouble, please contact local technical service center of our company for further information.





#### Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.